



TRUST "THE BISH"



AIRTIGHT | WATERPROOF | FLEXIBLE



CLEAR ADHESIVE PATCH

REPAIRS RIPS, TEARS & LEAKS IN VINYL & FABRIC

Use VINYL MENDER to patch and repair a variety of outdoor and indoor items. Works on in-field or at-the-spot repairs on vinyl upholstery including auto and RV seats and other smooth non porous fabrics, tents, tarps, rain gear, fishing waders and more.

VINYL MENDER uses Advanced Acrylic Adhesive technology to form a permanent seal to vinyl.

VINYL MENDER is the clear replacement for duct tape. The powerful clear adhesive does not migrate or ooze thus reducing the possibility of a sticky or unsightly mess. Use the patch to make fast repairs to Pool Liners, Towable Tubes, Inflatables and Poly-Tarps. It instantly seals seams, tears and pinholes, stops rips from spreading and acts as an abrasion -resistant shield on high-wear areas.

BISH'S ORIGINAL
**VINYL
MENDER**

JUST PEEL & STICK

REPAIRS TEARS AND HOLES IN:

- » TENTS
- » SAILS
- » MOTORCYCLE SEATS
- » BOAT COVERS
- » BOAT TOWABLES
- » CUSHIONS
- » FISHING WADERS
- » AWNINGS
- » SLEEPING BAGS
- » CAMPING PADS
- » INNER TUBES
- » UPHOLSTERY
- » TARPS
- » SEATING
- » AUTOS
- » BOATS
- » INFLATABLES
- » AIR MATTRESSES
- » JET SKIS
- » ATVs
- » SNOWMOBILES
- » GOLF CARTS
- » POOL LINERS
- » POOL TOYS

BONDS TO:

- » FIBERGLASS
- » VINYL SURFACES
- » NYLON
- » ACRYLIC FABRIC
- » LEATHER
- » NEOPRENE
- » METAL SURFACES
- » MAN-MADE FABRICS
- » POLYPROPYLENES
- » POLYETHYLENES
- » POLYURETHANES
- » FINISHED WOOD SURFACES
- » FABRICS - SYNTHETIC & NATURAL

WARRANTY: LHB Industries will not accept liability for more than product replacement.

GENERAL USE DIRECTIONS: Clean the surface to be repaired with an alcohol swab (provided) and let dry. Cut the Clear Adhesive patch to desired size. The Patch should be approx. 1-inch beyond the damage in all four directions. Peel the patch from its paper backing and smoothly apply to damaged area taking care to avoid trapping air bubbles. Press down firmly along all the edges of the repair. Repaired items should not be machine washed or dried. Note: Clear Adhesive Patch may be applied under water.

STEP-BY-STEP USAGE GUIDE & HINTS FOR EASE OF USE

ONE: Clean the surface to be repaired then allow it to dry. Alcohol swabs are provided but you can use a mixture of Isopropyl alcohol and water [50/50] as the cleaning solution.

TWO: Cut the Clear Adhesive Patch to a size 1-inch larger than the damaged area in all four directions. Round the corners of the patch to reduce the possibility of peel back. Rounded corner patches perform better than square corners.

THREE: Prepare the patch for application by peeling back a small portion of the liner. By peeling back approximately ½ inch of liner it allows the bonding of the Clear Adhesive Patch to start. At one end slowly remove more of the liner and simultaneously smooth the patch onto the repair, pressing firmly to push out any air bubbles.

FOUR: Press down firmly on the entire patch and rub hard along all the edges of the Clear Adhesive Patch.

NOTE: Acrylic Adhesive Technology delivers Hi-Tack initial bonding that is fully cured after 6 hours for a durable, long lasting Repair.



LHB INDUSTRIES
SAINT LOUIS, MO 63132
800.552.8252
TEARMENDER.COM

